

DIRECT-DRIVE TURNTABLE

PD-121/131

SERVICE MANUAL

MODEL: PD-121,131

Features of Black light by using a small
Cold Cathode Ultra violet light tube

This small discharge type tube was developed for use in our turntable. As its features far out weighed that of the conventional Orange Neon as strobo-scope timing light.


It differs in operation from the usual fluorescent tube in that it has no starting filaments, but instead has a small electrode near each main cathode at each end of the tube. So discharge is enabled by a high firing voltage (250 volts).

However, since mercury is used as the gaseous medium in the sealed tube operation at very low temperatures eg. below 5°C is very difficult. But with the special firing circuits used in the PD-121, operation is guaranteed from above 0°C .

This tube is characterized by


- 1) Low power consumption (0.7W)
- 2) Low operating temperature
- 3) Small-size
- 4) Long-life (20,000 hours)
- 5) Ultra Violet light at 3650 \AA .

So to make the strobo-scope pattern very clear as if to appear stationary, the tube is fired by short duration pulses, and to make for a high visibility "dayglo" type paint is used for the strobo markings, this type of paint converts Ultra violet light into visible coloured light.




ALIGNMENT PROCEDURE

- 1) PB-650 D.C. voltage adjust





2) Pre-adjust of the Turntable position

- a) After mounted every components on both the chassis and the panel, these two shall be put together.
- b) Loosen the 4 screws for provisional fixing, and put the turntable on.
- c) Provisionally fix the motor when the equivalent gap between the panel and the turntable is obtained as per the drawing. (The provisional fixing is possible with a (+) driver through the 2 holes for tightening of the motor-fixing (-) screw on the turntable.)



3) Pre-adjust of the Reed Switch and the height of the Selector Switch

- a) Hold the switch-button on the panel with the SCOTCH drafting tape etc, and put together with the chassis. Note that the chassis and the wood-frame should not be screwed together at this stage.
- b) Adjust the screw which fixes the switch-mount metal so that the button protrudes about 2mm from the panel-surface.
- c) Power-on with the mains cord connected to the rated AC mains power source.
- d) Operate the speed selector switch to check through the stroboscope whether smooth speed-selection is possible. (In case correct rotation is realized, the figures in the stroboscope are observed standstill.)
- e) When the above selection is found to be not smooth, re-check its operation by varying the position of the switch-mount metal, which is stated in the (b) clause.
- f) Further, when the operation checked in (e) is found unstable, check again with moving the Reed Switch as per the drawing.




FINAL ADJUST

1) Setting of the platter

After fixing the wood-frame and the chassis together with screws, the final check shall be made in the same procedure as stated in the section (2) pre-adjust.

2) Switch-button Height

Same procedure as made in the (3) - (b) pre-adjust. Adjust the 2 screws for the switch-mount metal at the bottom side of the chassis to obtain 2mm-protrusion from the surface of the panel.




3) Speed-Selection

Ascertain the firm selection of speeds by operating the selector. When it is unstable, adjust the 2 screws for the switch-mount metal. In case the section (2) is not fulfilled is (the buttons do not protrude from the panel, or the protrusion is extremely different on the ON-button and OFF-button), repeat the pre-adjust section (3).

4) Hinge-Height Adjustment


Set the acrylic cover to the hinge, and adjust as per the drawing.




5) Installation of the Tonearm Base

Install the base to the chassis. Turn the base to the clock-wise direction by $1/8$ rotation until it is locked, when ascertain that the base is firmly locked. Then press-in the lock-release button and turn the base to the counter-clockwise direction to remove the base. Try this procedure 2 or 3 times.


BLOCK DIAGRAM





CIRCUIT DIAGRAM FOR BLACK-LIGHT



※ NUMBERS ARE EQUIVALENT TO THE SOCKET NUMBERS.









PB-650

(120V version)




* F103 1.5A (PD121)
1A (PD131)

PB-653 (220V,240V version)



* F404 1.5AT(PD121)
1AT (PD131)
F405 1.5AT(PD121)
1AT (PD131)

PB-651A



MODEL: PD121 Replacement Parts List

PB-650	PB-653	PB-650	PB-653	PB-650	PB-653
R101 33K	(R401)	F102 0.1A	(-)	Q101 2SA733	(Q401)
102 10K	(402)	103 1A	(-)	102 2SD256	(402)
103 3.3K	(403)	(-) 0.5A	(F401)	103 2SC372	(403)
104 680	(404)	(-) 0.5A	(402)	D101 1N4003	(D401)
105 680	(405)	(-) 0.1A	(403)	102 1N4003	(D402)
106 10K	(406)	(-) 1A	(404)	103 W-04	(403)
107 10K	(407)	(-) 1A	(405)	104 1N4001	(404)
VR101 10K-B	(VR401)	C101 4.7uF 35V	(C401)	105 WZ-071	(405)
F101 0.5A	(-)	102 220uF 35V	(C402)	106 1K-188FM	(406)

PB-651

D201 1N4007	R205 47K	R215 4.7K	C204 100pF
202 W-04	206 1.8K	216 33K	205 2200pF
203 1N-4448	207 47K	217 3.9K	Q201 2SC945
204 1N-4448	208 33K	218 6.8K	202 2SC945
205 1N-4448	209 2.2K	219 1.8K	203 2SC945
206 1N-4448	210 4.7K	220 1.5K	204 2SC945
R201 560K	211 4.7K	221 1.2K	205 2SC1447
202 JFW-03(jumper)	212 10K	C201 4.7uF 350V	
203 JFW-03(jumper)	213 2.7K	202 0.001uF	
204 1.8K	214 4.7K	203 0.012uF	